

Potato Plant Probiotics

Potato Seeds Plant Probiotics Formulation by NTHRYS

Plant Probiotics Standardized by NTHRYS for Potato Seeds Cultivation addresses below parameters in order to assist farming community to achieve better profits in Potato Seeds Cultivation.

1. Increase in tuber yield and quality.
2. It protects the crop from pests and diseases, such as Potato Blight, Colorado Potato Beetle, and Potato Cyst Nematode.
3. Enhancement in Nutrient Uptake and Metabolic Health.
4. Improving Plant Vigor and Tuber Size.
5. Increases Leaf Size and Photosynthetic Efficiency.
6. Increases Chlorophyll Content.
7. Increases Soil Enzyme Activity and the Quantity and Biodiversity of Viable Microorganisms.
8. Enhancement in Rhizosphere Activity.
9. Solubilization of Phosphorus.
10. Solubilization of Potassium.
11. Increase Soil Fertility.

NTHRYS Research Team has formulated Potato Seeds Plant Probiotics Formulation using a battery of Microbial Consortium (> 20 strains) to address all the above Objectives.

NTHRYS Plant Probiotics should not be mistaken as Biofertilizers. They are next generation plant supporting microbiome to support respective farmers to gain good profits with their produce.

Application Process :

Soil Treatment Before crop initiation:

1. The soil is treated with **formulation**, before initiating Potato Seeds planting.
2. 3 Lit **offormulationis** mixed with 100 Kg of Farm Yard Manure (FYM) 1 to 2 days before planting per acre.

Seed Treatment :

1. Potato seeds (seed tubers) are treated with **formulation**.
2. The seed tubers are soaked in **formulation** for half an hour before planting. (Use a dilute solution **offormulation** for soaking).

Disease Management in Potato Seeds:

1. Potato Seeds suffer from various pests and diseases like Early Blight, Late Blight, and Scab.
2. Spraying **formulation** on the plant as well as at the base would help prevent these diseases and pest infestations.

Probiotic Dosage at Various Growth Phases:

1. **After Planting:** 500 ml **offormulation**+ 150 lit water + 1.35 kg of Epsom salt one day before spraying per acre. This should be done immediately after planting seed tubers and before sprouts emerge.
2. **Vegetative Growth Phase:** 1 lit **offormulation**+ 200 lit water + 1.8 kg of Epsom salt one day before spraying per acre until plants are fully established.
3. **Pre-harvest Phase:** 2 lit **offormulation** added to 300 lit of water + 2.7 kg of Epsom salt one day before spraying per acre a few weeks before harvesting to enhance tuber development and quality. **formulation** Spraying and **formulation**+ **FYM** mixture (3 Lit **offormulationis** mixed with 100 Kg of Farm Yard Manure (FYM) per acre) addition can be done once per every two weeks during active growth periods.

Issued by:

NTHRYS OPC PVT LTD

Ph: +91 - 7093184748

Web: www.nthryst.com

Email: smo@nthrys.com

Last Updated: 11 May 2024 1:45 am